

While all required textures are included here, the small size of the model may require trimming or other adjustment of some components.

Pivot beams, solebars and timbers (above for underframe, steps, etc.) fold and glue around card to create structural timbers. Headstock should be created as part of end to ensure structural integrity. Extra headstock print covers exposed end of card, trim to fit.

The floor must fit inside headstock/walls with side walls extending roughly 1/3rd of solebar width below bottom of floor. Roof texture is oversize, trim to fit and colour underneath to avoid exposed white card.


Interior bracing may be required to keep walls straight or to support roof. Trim heights as needed and sides of template evenly to fit inside walls.

Decide on method of coupling before starting construction and adapt kit as needed. Small HOn30/OO9 bogies should work satisfactorily, adjust location of pivot beam (bolster) if necessary. Fine pins, set in pre-drilled holes make queenposts with fishing line or brass wire for truss rods.



Sides extend below bottom of floor, partly obscuring solebar. Underbody detail shown here for location. Metal sheet (left) for underfloor bracing, etc.

Buderim Coach - HO Scale (1:87)



Kit contains textures © Clever Models plc; CG Textures
 QldRailHeritage.com/mrqc, © February 2014